



## Meinberg Radio Clocks

Lange Wand 9  
31812 Bad Pyrmont, Germany  
Phone: +49 (5281) 9309-0  
Fax: +49 (5281) 9309-30  
<http://www.meinberg.de>  
[info@meinberg.de](mailto:info@meinberg.de)

## LANTIME M300/TCR: IRIG Time Server with Time Code Receiver

The Meinberg LANTIME M300/TCR IRIG time server provides accurate time to networks of any size. It synchronizes all systems either NTP- or SNTP-compatible and comes with a built-in Meinberg TCR module which decodes a [1][IRIG/AFNOR](#) signal from any compatible time code generator. A highly stable and precise oscillator is capable of bridging failures or a temporary loss of the IRIG signal..

### Key Features

- Synchronization of NTP and SNTP compatible clients
- Web based status and configuration interface [2][\(Demo\)](#) and console based graphical configuration utility
- Supported net protocols: IPv4, IPv6, NTP, SNTP, DAYTIME, DHCP, HTTP, HTTPS, FTP, SAMBA, SFTP, SSH, SCP, SYSLOG, SNMP, TIME, TELNET, W32TIME
- Alert-Notification system of status change by Email, WinMail, SNMP or an external connected display
- Full SNMP v1,v2,v3 support with own SNMP-daemon for status and configuration and SNMP Trap messages
- USB port for performing updates, lock front panel, and backup/restore configuration and log files.
- Optional expansions and/or configurations available: [3][Product Options](#)

## Description

The LANTIME M300/TCR Network Time Server combines a Time Code Receiver module with an embedded Linux computer.

The GNU/Linux operating system of the LANTIMEs SBC (Single Board Computer) has been optimized to ensure a high level of security and reliability.

A large display shows the state of the internal IRIG/AFNOR receiver and the NTP subsystem.

The configuration of the system can be done by using a standard web browser to access the extensive but straightforward html interface. Alternatively a text based and menu driven setup utility can be started from the shell prompt after logging into the unit via Telnet or SSH.

The security-related features of LANTIME time servers satisfy highest demands. The time synchronization data can be reliably signed and secured by symmetric keys (MD5) and the NTP autokey procedures. This protects the clients against manipulated time and man-in-the-middle attacks and allows them to verify that the NTP packets they received were sent by the LANTIME. Additionally the whole LANTIME configuration can be done by using encrypted channels (e.g. SSH, HTTPS or SNMPv3). Every unused/unneeded protocol can be disabled in order to reduce possible points of attack.

In order to support network management systems the LANTIME time servers offer an extensive SNMP interface, which can be accessed by SNMP V1, V2.c and V3. It allows the monitoring of all relevant system parameters (including operating system parameters, network interface statistics, detailed IRIG and NTP status information as well as the complete system configuration) and can be used to alter the LANTIME configuration via SNMP set commands, too.

LANTIME time servers are designed to be deployed in IPv6 networks, the NTP time synchronization as well as the configuration interfaces (Web-based, SSH and SNMP) comes with IPv6 support. You can assign several IPv6 addresses and the system supports automatic configuration by IPv6 autoconf.

Because of its modular system architecture it is possible to equip a LANTIME time server with up to two additional ethernet ports and a number of different reference time sources. Optionally several additional frequency-, serial string- and pulse outputs are available. Besides that two oscillators ensure fantastic holdover characteristics (e.g. when the IRIG/AFNOR signal is disturbed or not available): the reliable temperature controlled base model (TCXO) and the excellent oven controlled OCXO--LQ.

## Characteristics

<b>Type of receiver</b>	Integrated [4] <a href="#">IRIG A/B Time Code Receiver TCR511</a>
<b>Display</b>	LC-display, 2 x 40 characters, with backlight
<b>Control elements</b>	Eight push buttons to set up basic network parameters and to change receiver settings
<b>Status info</b>	Four bicolor LEDs showing status of: <ul style="list-style-type: none"> <li>- reference time</li> <li>- time service</li> <li>- network</li> <li>- alarm</li> </ul>
<b>IRIG Time Code Input</b>	IRIG-A133, A132, A003, A002, B123, B122, B003, B002, IEEE1344 and AFNOR NFS 87-500 (other codes upon request)
<b>Frequency outputs</b>	10 MHz via female BNC connector, TTL into 50 Ohm Accuracy depends on oscillator (standard: TCXO), look at [5] <a href="#">oscillator options</a>
<b>Pulse outputs</b>	Pulse Per Second (PPS), TTL level, pulse width: 200ms
<b>Precision of timebase</b>	+/-10us referred to reference marker in synchronous mode
<b>Network Interface</b>	2 x 10/100 MBit with RJ45
<b>Universal Serial Bus (USB) Ports</b>	1x USB Port in front panel: <ul style="list-style-type: none"> <li>- install firmware upgrades</li> <li>- backup and restore configuration files</li> <li>- copy security keys</li> <li>- lock/unlock front keys</li> </ul>
<b>Single-Board-Computer</b>	i386 compatible 500Mhz CPU, 256 MB RAM
<b>Operating System of the SBC</b>	Linux with nano kernel (incl. PPSkit)
<b>Network protocols OSI Layer 4 (transport layer)</b>	TCP, UDP
<b>Network protocols OSI Layer 7 (application layer)</b>	TELNET, FTP, SSH (incl. SFTP, SCP), HTTP, HTTPS, SYSLOG, SNMP
<b>Internet Protocol (IP)</b>	IP v4, IP v6
<b>Network Autoconfiguration Support</b>	IPv4: Dynamic Host Configuration Protocol - DHCP (RFC 2131) IPv6: Autoconfiguration Networking - AUTOCONF
<b>Network Time Protocol (NTP)</b>	NTP v2 (RFC 1119), NTP v3 (RFC 1305), NTP v4 (no RFC) SNTP v3 (RFC 1769), SNTP v4 (RFC 2030) MD5 Authentication and Autokey Key Management
<b>Time Protocol (TIME)</b>	Time Protocol (RFC 868)

<b>Daytime Protocol (DAYTIME)</b>	Daytime Protocol (RFC 867)
<b>IEC 61850</b>	Synchronization of IEC 61850 compliant devices by using SNTP
<b>Hypertext Transfer Protocol (HTTP)</b>	HTTP/HTTPS (RC 2616)
<b>Secure Shell (SSH)</b>	SSH v1.3, SSH v1.5, SSH v2 (OpenSSH)
<b>Telnet</b>	Telnet (RFC 854-RFC 861)
<b>Simple Network Management Protocol (SNMP)</b>	SNMPv1 (RFC 1157), SNMPv2c (RFC 1901-1908), SNMP v3 (RFC 3411-3418)
<b>Power supply</b>	85-264VAC (50/60Hz)
<b>Form Factor</b>	19" aluminium case (1U) Schroff Multipac
<b>Ambient temperature</b>	0 ... 50°C / 32 ... 122°F
<b>Humidity</b>	Max. 85%
<b>Scope of supply</b>	Time Server, power cable, printed Quick-Start manual (detailed reference manual is stored as a PDF file inside the unit and can be downloaded, read and printed with a webbrowser)
<b>Technical Support</b>	Meinberg offers free lifetime technical support via telephone or e-mail.
<b>Warranty</b>	Three-Year Warranty
<b>Firmware Updates</b>	Firmware is field-upgradeable, updates can be installed directly at the unit or via a remote network connection. Software updates are provided free of charge, for the lifetime of your Meinberg product.
<b>RoHS-Status of the product</b>	This product is fully RoHS compliant
<b>WEEE status of the product</b>	This product is handled as a B2B category product. In order to secure a WEEE compliant waste disposal it has to be returned to the manufacturer. Any transportation expenses for returning this product (at its end of life) have to be incurred by the end user, whereas Meinberg will bear the costs for the waste disposal itself.
<b>Options and Accessories</b>	Optional add-ons and accessories: [3] <a href="#">Product Options</a>
<b>Additional Information</b>	Additional information about the Meinberg LANTIME family of NTP time servers and other LANTIME models can be found on the [6] <a href="#">LANTIME NTP Time Server Family Page</a>

#### Manual

The english manual is available as a PDF file: [7][Download \(PDF\)](#)

**Links:**

- [1] <http://www.meinberg.de/english/products/./info/irig.htm>
- [2] <http://www.meinberg.de/cgi-bin/main.cgi>
- [3] <http://www.meinberg.de/english/products/./lantime-m300-tcr-options.htm>
- [4] <http://www.meinberg.de/english/products/tcr511.htm>
- [5] <http://www.meinberg.de/english/products/./specs/gpsopt.htm>
- [6] <http://www.meinberg.de/english/products/./ntp-time-server.htm>
- [7] <http://www.meinberg.de/download/docs/manuals/english/lantime-m300-tcr.pdf>